

# CDU Commands

## Universal CDU commands

Command	Description
Alt+A	Access the departures and arrivals page
Alt+C	Clear the Scratchpad
Alt+E	Execute Key (when available)
Alt+F	Fixes page
ALT+G	Legs Page
Alt+H	Hold page
ALT+I	Init/Ref Page
Alt+P	Progress page
ALT+R	Refresh the CDU display
Alt+S	jump to the scratchpad edit field. (After entry, press enter to send the buffer to the Aircraft CDU Scratchpad)
Alt+T	Route page
ALT+X	CDU Delete Key
ALT+ Up Arrow	Previous CDU Page
Alt+ Down Arrow	Next CDU page
Alt+home	Jump to the FMC display

## Line Select Key Commands

Depending on how you have the line select mode set, press either ctrl and the numbers 1 through 6 to activate the left line select keys, and Alt+1 through 6 for the right. The alternative mode uses function keys F1 through F12, with F1 through F6 as the left side, and F7 through F12 as the right side. To switch between modes, use the keyboard command Ctrl+I.

# PMDG 777 CDU Specific Commands

Command	Description
Alt+M	FMC Com page
ALT+N	ATN. page
ALT+O	Radios page
Alt+U	Access CDU main menu
ALT+V	V-NAV Page

# PMDG 737 CDU Specific Commands

Command	Description
Alt+B	Climb
Alt+D	Descent
Alt+M	Menu
Alt+N	N1 limit
Alt+Z	Cruise

---

Revision #3

Created 5 April 2025 23:24:18 by Daniel Wolak

Updated 6 November 2025 20:56:32 by Gus Pacleb