

PFD Commands

PFD Commands

The following commands can be used to jump to various sections of the PFD (Primary Flight Display) when it has focus.

Command	Description
A	AGL Altitude
D	Flight Director Bank
H	Heading
I	Indicated Airspeed
G	Ground Speed
M	Mach Number
V	Vertical Speed
\ T	Altimeter
P	Pitch
B	Bank
F	Flight Director Pitch

Revision #1

Created 7 April 2025 12:56:11 by Daniel Wolak

Updated 7 April 2025 13:06:32 by Daniel Wolak